

**OCPP -80Y** **80** **USB**  
 (OCPP -80Y)

**OCPP -80Y:**

1. OCPP -80Y 80 USB
2. OCPP -80Y 1
3. 160mm / s
4. Supports 256KB NV Logostorage 2 M

**OCPP -80Y:**

OCPP -80Y:	OCPP -80Y
OCPP -80Y:	160MM /
OCPP -80Y:	79.5 ± 0.5mm
OCPP -80Y:	Φ80mm
OCPP -80Y:	0.06-0.08mm
OCPP -80Y:	576 / 512 /
OCPP -80Y:	3.75mm(ESC / POS)
OCPP -80Y:	ESC / POS
OCPP -80Y:	1
OCPP -80Y:	100
OCPP -80Y:	2048Kbytes
NV:	256Kbytes
OCPP -80Y:	AC110V / 240V 50 ~ 60HZ
OCPP -80Y:	DC 24V / 2.5A
OCPP -80Y:	DC 24V / 1A
OCPP -80Y:	(80~10) (45~0)
OCPP -80Y:	(80-10) (45-0)
OCPP -80Y:	90~10 (°C60~10-) (°C60~10-)
OCPP -80Y:	ANK FontA: 1.5 * 3.0mm / FontB:1.1 * 2.1mm
OCPP -80Y:	UPC-A / UPC-E / JA(EAN13)/ JAN8(EAN8 / CODE39 / ITF / CODE93 / CODE128
OCPP -80Y:	PC347(PC850(PC860(PC863(PC865(WPC1252(PC866(# PC852(Latin2) PC858IranIIPT151(1251)
OCPP -80Y:	1.25 :



OCPP-80Y





OCPP-80Y



**Attention:** Press FEED or re-start to reset cutter when it or cover stuck, if not, open here and turn the gear to reset cutter

POWER ERROR PAPER FEED





# OCPP-80Y





OCPP-80Y

