

# 76 USB

## OCPP-764

□□□□

□□	□□□□	□□□□□□
	□□□□	75.5±0.5×φ58mm
	□□□	80□□
	□□□□	3.2line /□
	□□□□	USB
	□□□□	□□EPSON / TM210 / TM220
	□□□	10□□
□□□□□□	□□□□	ANK□FontA□9×9dots□FontB□7×9dots; □□□□□□□□□□16×16□
	□□□□□	PC437/Katakana/PC850/PC860/PC863/PC865/ WPC1252/PC866/PC852/PC858
□□	□□	DC24V / 1A
	□□□□□□	AC110 / 220V□50-60Hz□□; DC24V /2.5A□□
□□□□	□□□□□kg□	2.3KG / 2.5KG□□□□□
	□□□□	24.2CM * 15.7CM * 13.5CM
□□	□□□□	0-45□□□□
	□□□□□□	10-80□
□□□□□	□□□	□□
□□□□	76□□□□□	1□□□□□
	□□□	1□
	□□□	1□x DC24V / 2.5A□□□
	□□□□	1□X CD-ROM
□□□□	□□□□	55 * 46 * 36□□□□
	□□□□/□	8□/□
	□□	19.5KG / 21KG□□□□□

□□□□□□

× × × × × × × × × × × × × × × ×