



OCP-80H



Attention: Press FEED or re-start to reset cutter when it or cover stuck, if not, open here and turn the gear to reset cutter

POWER ERROR PAPER FEED





OCP-80H



