

80Pos

OCPP -88A

pos

pos8080

- 1.;
- 2.300/;
- 3.;
- 4.
- 5.USB
- 6.;
- 7.;
- 8.;
- 9.AndroidSDK;
- 10.100;
- 11.EP SON ESC / POS

pos

pos	pos
pos	576/512/; 24x24,18030ANK;
pos	A12 * 241.5W* 3.0Hmm; B9 * 171.1* 2.1mm 24 * 243.0* 3.0mm
pos	JUPC-A / UPC-E / JAN13EAN13/ JAN8EAN8/ CODABAR / ITF / CODE39 / CODE93 / CODE128QR
pos	250 mm / sec300mm / sec
pos	USBUSB + USB + LANUSB + + USB+ USB + LAN
pos	EPSON ESC / POS
pos	Win9X / Window XP / Win VISTA / WIN2000 / Win2003 / Win / Win 7 8 / win8.1 / Linux ESPONSDKAndroid
pos	79.5±0.5 mm72
pos	83
pos	0.06-0.08mm
pos	
pos	
pos	DC24V / 2.5A
pos	0-45
pos	10-80
pos	190 * 145 * 145MM
pos	1.60

OCPP	P / N.	□□
	OCPP -88A-U	USB□□□□□□□□
	OCPP -88A-UR	USB + □□□□□□□□
	OCPP -88A-UL	USB + LAN□□□□□□□□
	OCPP -88A-URL	USB + □□+ LAN□□□□□□□□
	OCPP -88A-W	□□+ USB□□□□□□□□
	OCPP -88A-BUL	□□+ USB + LAN□□□□□□□□
	OCPP -88A-U0	USB□□□□□□□□
	OCPP -88A-UR0	USB + □□□□□□□□
	OCPP -88A-UL0	USB + LAN□□□□□□□□
	OCPP -88A-URL0	USB + □□+ Lan□□□□□□□□
	OCPP -88A-W0	□□+ USB□□□□□□□□
	OCPP -88A-BUL0	□□+ USB + LAN□□□□□□□□



□□□□□

[*□□](#)

[*□□□□](#)

[*□□](#)

[*□□□□WinXP Win2000 WinVista Win8-32bit](#)

[*□□□□Win8-64bit](#)

[*Linux□□□□](#)

[*□□□□□□□□](#)

[*USB Printdemo□□□□□□□□](#)

[*SDK □□Android](#)

[*□□ □](#)