



OCPP-80P



Attention: Press FEED or re-start to reset cutter when it or cover stuck. If not, open here and turn the gear to reset cutter.





OCPP-80P





OCPP-80P





OCPP-80P





OCPP-80P





OCPP-80P

