

Linux
OCPP-586

□□□

□□□□	□□
□□□□	384dots/line□203DPI□
□□□□	384dots/line□ANK□□□□□A□12 * 24□□1.5□□□* 3.0□□□mm □□/□□□□24 * 24□□3.0□□□* 3.0□□□mm
□□□□	AN13□EAN13□ AN8□ EAN8□ CODE39
□□□□	□□ EPSON ESC / POS
□□	OEM437/Katakana/OEM850/OEM860/OEM863/OEM865/West□□/□□/□□□□/□Europe/Iran/WPC1252/OEM866/OEM852 / OEM858/IranII/Latvian / Arabic/PT151□1251/OEM747 / WPC1257/Vietnam / OEM864/Hebrew/WPC1255/Thai
□□□□	90mm/sec
□□□□	57.5±0.5□□
□□□□	0.06-0.08□□
MCBF□□□□	50km
□□	190 * 132 *119□□
□□	1.2KG
□□□□□	□□□□□
□□□	□□□□□□□□□□□□□□□□□□
□□	φ75MM
□□	RS-232□□□□□USB□LAN
□□	Win9X/Win2000//Win2003/Win Vista/ Win 7/Window XP /, □□ESPON
□□□□□	DC12V/3A
□□□□	DC12V/1A
□□□□	0-45°C□ □□□ 10-80□
□□□□	-10-60°C□□□□ 10-90□

□□□□□□□

