

Android pos

M / N POS-Q3 / Q4

Android 6.0;
 2G / 3G / 4G;
 Q3 3G MTK80 1.3GHz;
 Q4 4G Cortex A53 1.25G Hz;
 1G RAM + 8G 2G + 16G
 58mm;
 500;
 32GB TF;
 CCD;
 NFC HF;
 12V;
 5000mAh

O / S	Android 6.0
	MTK80 1.3GHz Q3,3G Cortex A53 1.25G Hz Q4,4G
	1GB RAM 2GB
	8GB FlashStandard 16GB
	5.5 1280 x 720
	5MP
	1D CCD
RFID	13.56MHZ 14443A NFC HF
	GSM900 / 1800 WCDMA2100 TD-SCDMA B34 B39 / FDD-LTE B1 B3 / TDD-LTE B38 B39 B40 B41
	4.0
	WIFI 802.11 b.g.n.
	1W
	MIC
I / O	USB SIM
	7.4V / 5000mAh
	58mm 90mm / s 50
	42
	100-240V / 1.5A 50 / 60Hz 12V 1A



POS-Q3/Q4





POS-Q3/Q4





POS-Q3/Q4





POS-Q3/Q4





POS-Q3/Q4





POS-Q3/Q4





一、前言

本手册旨在为用户提供有关Aocom POS-Q3/Q4手持设备的详细操作指南。请仔细阅读本手册，以确保正确使用设备。

本手册适用于Aocom POS-Q3/Q4手持设备的所有型号。

2. 设备组成及接口

本设备由以下部分组成：

1. 主机：Aocom POS-Q3/Q4手持设备主体。

2. 配件：包括充电器、数据线、说明书等。
 3. 接口：设备背面设有USB接口、充电接口等。

3. 安装

OCOM设备在安装前，请确保设备处于关机状态。

1. 将设备插入充电器底座，确保设备与底座接触良好。

