



## How to install the printer's drive under operation windows 7 64


Go to the Start Menu < Device&Printer, click add a printer to start the add printer wizard





Add a local printer





Choose a printer port and click next




Click have disk



Click browse, locate the correlative driver



Click OK



Choose the right printer model, click next

Notes: POS series printers now available include:

POS-58 Series (without cutter)

POS-58C Series (with cutter)


POS-80 Series (without cutter)

POS-90 Series (without cutter, 90mm/s)


POS-80C Series (with cutter)

POS-76 Series (without cutter)


POS-76C Series (with cutter)




Use the driver that is currently installed, then next



Next




Finish




Printer driver installed successfully






Right Click the printer properties



Printing test page to check if your printer working properly

If there are troubles information, check the printer port is the same with the drive

port, drive port selection see below:



Any problem pls contact with our technician.